



MEDEEK DESIGN
 INC.
 1000 S. 1000 E.
 SUITE 100
 DENVER, CO 80202
 (303) 733-1111
 WWW.MEDEEK.COM

PLAN NO. **RH3080**
 SCALE 1/2" = 1'-0"


DESIGNED BY: **NPW**
 DATE: **9/12/2015**

SHEET CONTENTS:
ELEVATIONS
ASSEMBLY DETAILS


REVISION HISTORY:	CUSTOMER:	LOCATION:

CUSTOMER:
 LOCATION:



SHEET **1** OF **2**




RIGHT ELEVATION
 SCALE: 1"=1'-0"





REAR ELEVATION
 SCALE: 1"=1'-0"



LEFT ELEVATION
 SCALE: 1"=1'-0"



FRONT ELEVATION
 SCALE: 1"=1'-0"



1 ACCESS DOOR DETAIL
 SCALE: 3/4"=1'-0"

GENERAL ASSEMBLY NOTES:

1. USE ROOF CEMENT BETWEEN 15# FELT AND PLYWOOD AND BETWEEN 15# FELT AND ROLLED ROOFING FOR A MORE SECURE ATTACHMENT.
2. PRE-DRILL ALL SCREW HOLES TO AVOID SPLITTING WOOD.
3. PAINT ALL EXPOSED WOOD WITH AN OIL BASED PAINT TO EXTEND SERVICE LIFE OF STRUCTURE.
4. USE T-25 STAPLES (9/16") WITH A ROUND CROWN TO ATTACH WIRE MESH TO WOOD FRAMEWORK. SPACE STAPLES APPROX. 3" MIN.
5. WIRE MESH SPACING CAN BE DECREASED FOR ENCLOSING SMALLER PETS.
6. ATTACH CARRY HANDLES AFTER WIRE MESH IS INSTALLED.
7. WIRE MESH CAN BE OPTIONALLY INSTALLED ON BOTTOM OF ENCLOSURE FOR A MORE SECURE ENVIRONMENT.